



### DSDL ARM Parts Breakdown

<u>Key</u>	<u>Part #</u>	<u>QTY</u>	<u>Description</u>
A	160713T	2	Internal Support Spacer
B	413019	1	Luminaire power receptacle
C	103045	1	Lamp Arm
D	160715T	1	Swivel Bracket w/ supports
E	100699	2	Wall Arm
F	160716T	1	Arm Stop
G	820213	4	Closure Cap
H	160717T	1	Wall Mount Bracket
I	733016	1	Power Cord
J	413007	3	Strain Relief Bushing