


COZY PRODUCTS

Safe, Energy-Saving Personal Heaters

Formerly "Indus-Tool"

300 N. Oakley Blvd www.cozyproducts.com
Chicago, IL 60612 sales@cozyproducts.com
Tel: 312 226-2473
Fax: 312 226-2480

REORDER: #FW 14" x 21" 90 watts
#FWB 16" x 36" 135 watts



FOOTWARMER

Thermostatically-controlled
uniform radiant heat

INSTRUCTIONS:

- 1 Plug in
- 2 Push switch on cord to "ON" position (switch is illuminated when "ON")
- 3 Use on floor wherever you want extra warmth
- 4 Observe safety precautions:
 - Do not cover
 - Do not fold or twist
 - Do not use if cut or damaged
 - Keep from pets and children
 - Keep dry and free from obstruction
 - For "indoor use" only

GENERAL INFORMATION:

HOW IT WORKS

FOOTWARMER has been pre-tested and set to the correct temperature for use. The mat has been designed so warmth travels upward, circulating around your feet and legs.

TEMPERATURE

FOOTWARMER contains an electric heating element that produces a uniform radiant heat. It is thermostatically controlled so that the heat will be maintained at a constant temperature. The heating element is molded within the rubber to eliminate the danger of fire or electrical shock. (As with any new heated rubber product, the rubber odor may be quite noticeable when plugged in for the first time. This is temporary, and will dissipate quickly.)

PLACEMENT

Take care as to what type of surface you place the mat on – some delicate surfaces may discolor or crack from even this gentle heat. If you are not sure, place some cardboard under the mat for insulation.

IMPORTANT: PLEASE READ BEFORE USE

This appliance has a polarized plug. To reduce risk of electric shock, this plug is intended to fit in a polarized outlet one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.