

**INSTALLATION INSTRUCTIONS & PARTS LIST
MODELS; MARK12-110P & RF6110-P**

INSTALLATION;

The MARK12 is equipped with two ‘pigtail’ power supply wires and the RF6 is fitted with a two conductor AC power cord. If ‘pigtail’ connection is desired in the RF6, the cord can be removed from the side of the housing, after cutting away the plug and routed through the bottom.

- 1) Remove the rotating light mechanisms from the housing(s) and set aside.
- 2) Using the housing as a template, drill three holes equally spaced for flush mounting. A 1” (i.p.s.) flange is available for pipe mounting applications. The RF6 housing is equipped with a 7/8” d. hole in the center for installation of a ½” ETW fitting if needed.
- 3) When making power connections, observe convention in connecting 115 v. AC high side to the black load wire of the MARK12 and the smooth conductor of the power cord on the model RF6, (when you choose to remove the AC plug and wire through the bottom.
- 4) Replace the mechanisms in the housings, apply power before replacing the domes. If lights fail to operate check your new connections and verify that there is 115 v. AC power present.

MODEL	ITEM	TL PART #	COMMENTS
MARK 12	Lamps	420418	G.E. or equal #4435
RF6-110	Lamps	420420	G.E. or equal #4416-1
MARK 12, RF6-110	Motor	163230T	
MARK 12, RF6-110	Transformer	623010	
MARK 12, RF6-110	Drive Belts	800570	
MARK 12, RF6-110	Flange mount	RFPM	Includes mounting hardware
RF6-110	Dome, specify color	200514	Amber
		200513	Red
		200515	Crystal
		200512	Blue
		200516	Green
MARK12	Dome, specify color	200536	Amber
		200535	Red
		200533	Crystal
		200534	Blue
		200537	Green

WARRANTY

If it appears within one year from date of delivery to Purchaser that any products or component parts do not conform exactly to the specifications and physical descriptions referred to above. The Purchaser, at its expense, shall return the product or component parts to the Seller together with a report of defects. The Seller shall review the inspection report and inspect the items and shall authorize, at its option, either the repair or replacement of any non-conforming products or component parts. The liability of the Seller to the Purchaser arising out of the supply of or the use of the products or component parts, whether on warranty, contract or negligence is limited. Liability shall not in any case exceed the amount to be paid by the Seller in obtaining and repair or replacement of non-conforming products or component parts, and upon the expiration of the warranty period all liability of the Seller shall be terminated. The Seller makes no claim as the suitability of its product for the use intended.

950257 REV.11/03