



TB8 Internal Parts Breakdown

Key	Part #	Description
A	166022T	Linkage Assembly
B	196007A	Small Gear Assembly
C	196001A	Large Gear Assembly
D	556028	Motor, 12VDC with Wire
E	716014	Flexible Lamp Wire



TB8 Rings Parts Breakdown

Key	Part #	Description
A	136021	Lamp Outer Ring
B	126004	Dog Point Gimble Screw
C	156000	Flanged Bearing
D	136022	Lamp Inner Ring
E	300427	#10-24 Fastening Nut
F	310600	Lamp Retaining Clip (excluding L1)