INSTALLATION:

- 1) *To mount on a flat surface* without the use of the ETW fitting, disassemble the light and use the base housing as a drill template. (HINT: Leave the dome clips in the housing.)
- 2) To use a 'pigtail connection instead of the cord with plug: Cut the plug from the end of the power cord. Slit the insulation and strip each wire about ½". Feed the wires through either the ETW fitting for junction box mount or through the hole in the center of the housing for surface mounting. Be sure to plug the hole with the fitting provided.
- 3) You may use self threading screws for blind holes or machine screws with and nuts when there is access to the opposite face of the mounting surface. It is a good idea to use washers under the heads of the screws in the interior of the housing. Pass the power wires through the hole in the center.
- 4) To mount with $\frac{1}{2}$ conduit use the fitting provided, there is no need to drill holes.
- 5) When the housing is mounted, install the light mechanism. Before replacing the dome see the next paragraph for adjusting the reflector. When that is accomplished, put on the dome and secure with the three brackets.

OPERATION:

The reflector can be aligned to throw the beam of light upward, downward or straight ahead. Gently maneuver the reflector to obtain the desired result. Be sure to test the action to see that there is no interference of the rotation of the reflector.

RELAMPING:

Remove the dome, leave the clips in place. Gently unscrew the lamp from the socket. You may have to tilt the lamp slightly to clear the socket in order to remove it. Replace with a lamp no larger than 100 watts and the same globe size or smaller.

| DESCRIPTION |
|----------------------------|
| Motor, 115 v. AC only |
| ETW fitting kit, |
| Lamp, 100A/CL, 100 w. MAX. |
| Dome, AMBER, |
| Dome, RED |
| Dome, BLUE |
| Dome, GREEN |
| Dome, CRYSTAL (Clear) |
| Snap-in plug, ½" |
| |

REPLACEMENT PARTS

All Domes are made from unbreakable Polycarbonate material

LIMITED WARRANTY

If it appears within one (1) year from the date of delivery to Purchaser that any products or component parts do not conform exactly to the specifications and physical dimensions referred to above, and the Purchaser, at its expense, returns the product or component parts to the Seller together with a report of defects, the Seller shall review the inspection report and inspect the items and shall authorize, at its option, either the repair or replacement of any non-conforming products or component parts, whether on warranty, contract of negligence, shall not in any case exceed the amount to be paid by the Seller in obtaining and repair or replacement of non-conforming products or component parts, and upon expiration of the warranty period, all liability of the Seller shall be terminated.

Seller shall not be liable for any injury, loss or damage, direct or consequential arising out of the use or the ability to use the product.

This warranty gives specific legal rights, You may have other rights which vary from state to state.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so that the above limitation of exclusion may not apply to you.

WARNING: The individual user should take care to determine prior to use whether this device is suitable, adequate or safe for the use intended. Since individual applications are subject to great variation, the manufacturer makes no representation or warranty as to suitability or fitness of these devices for any specific application.